




SERVICE MANUAL 440 SERIES DIGGER MODELS



Example Part Number



THIS SERVICE MANUAL IS EFFECTIVE:
S/N: 70000 TO CURRENT
DATE: 5-2006 TO CURRENT
VERSION: SMD44081-44F95D9


NOTE: Individual customer specifications (spindle mounting, sprocket pilot, brake assembly, etc.) may vary from exploded drawing and standard part numbers shown. If applicable, refer to customer drawing for details.



Exploded View Drawing 44081-44F95D9

MODEL 44081-44F95D9 DIGGER


ITEM	QTY	DESCRIPTION	PART NO.
1	1	BASE-"F" FLANGLESS	42-004-3022
2	1	OUTPUT SHAFT-4" SQUARE	42-004-4102
3	1	COVER (4 BOLT "D")	25-004-1232
4	1	INPUT GEAR	25-004-1762
5	(1)	CARRIER ASSEMBLY- STAGE 1	25-005-2201
5A	1	CARRIER	25-004-1692
5B	3	PLANET GEAR	25-004-1712
5C	3	PLANET SHAFT	25-004-1442
5D	36	PLANET ROLLER	01-106-0010
5E	6	THRUST WASHER	13-004-1582
5F	9	ROLLER SPACER WASHER	13-004-1592
5G	3	ROLL PIN	01-153-0020
6		SUN GEARS	
6A	1	SUN GEAR (STAGE 2)	42-004-1512
6B	1	SUN GEAR (STAGE 3)	42-004-1472
7	(1)	CARRIER ASSEMBLY- STAGE 2	42-005-0101
7A	1	CARRIER	42-004-1062
7B	3	PLANET GEAR	42-004-1102
7C	3	PLANET SHAFT	42-004-1342
7D	60	PLANET ROLLER	01-106-0040
7E	6	THRUST WASHER	42-004-1362
7F	6	ROLLER SPACER WASHER	42-004-1352
7G	3	ROLL PIN	01-153-0220
8		RING GEARS	
8A	1	RING GEAR (STAGE 1)	25-004-1562
8B	1	RING GEAR (STAGE 2)	42-004-1042
8C	1	RING GEAR (STAGE 3)	42-004-1032
9	(1)	CARRIER ASSEMBLY- STAGE 3	42-005-0131
9A	1	CARRIER	42-004-1402
9B	3	PLANET GEAR	42-004-1092
9C	3	PLANET SHAFT	42-004-1332
9D	120	PLANET ROLLER	01-106-0040
9E	6	THRUST WASHER	42-004-1362
9F	9	ROLLER SPACER WASHER	42-004-1352
9G	3	ROLL PIN	01-153-0220
10		THRUST WASHERS & BEARINGS	
10A	1	THRUST SPACER	25-004-1842
10B	2	THRUST WASHER	01-112-0510
10C	1	THRUST BEARING	01-112-0500
10D	1	CARRIER THRUST WASHER-STAGE 1	25-004-1132
10E	1	CASE THRUST WASHER-STAGE 1	25-004-1752
11		SEALS & O-RINGS	
11A	2	O-RING - STAGE 1	01-402-0020
11B	3	O-RING - STAGES 2 & 3	01-402-0840
11C	1	OUTPUT SHAFT SEAL	01-405-0770
12		OUTPUT SHAFT BEARINGS	
12A	1	OUTER CONE	01-102-0290
12B	1	OUTER CUP	01-103-0290
12C	1	INNER CONE	01-102-0280
12D	1	INNER CUP	01-103-0280
13		HARDWARE	
13A	20	HEX CAP SCREW - 5/8-11 UNC - 9.5	01-150-1950
13B	20	HEX CAP SCREW - 5/8-11 UNC - 4.0	01-150-1880
13C	40	5/8 HELICAL SPRING LOCK WASHER	01-166-0040
13D	4	HEX CAP SCREW 3/4-10 UNC - 1.75	01-150-1890
13E	4	3/4 HELICAL SPRING LOCK WASHER	01-166-0360
14		PLUGS/ZERK	
14A	1	HOLLOW HEX PLUG -12 SAE	01-208-0030
14B	3	PIPE PLUG (3/4 NPT MAGNETIC)	01-207-0100
14C	1	PIPE PLUG (1/4 NPT)	01-207-0020
15		MISCELLANEOUS	
15A	1	STAGE 1 RING ADAPTER	42-004-2072
15B	1	BAIL ASSEMBLY	42-005-0171
15C	*	SHIM	42-004-1202
15D	1	LOCK RING	42-004-1212
15E	1	SPLIT RING (L-SEGMENT-425)	42-004-1222
15F	1	SUN GEAR RETAINING RING - STAGE 2	01-160-0740
15G	1	SUN GEAR RETAINING RING - STAGE 3	01-160-0690
15H	1	CARRIER RETAINING RING - STAGE 3	01-160-0680
16	1	MOTOR	01-304-0950



LUBRICATION & MAINTENANCE

Using the chart below, determine an appropriate lubricant viscosity. Use only EP (extreme pressure) or API GL-5 designated lubricants. Change the lubricant after the first 50 hours of operation and at 500 hour intervals thereafter. The auger drive should be partially disassembled to inspect gears and bearings at 1000 hour intervals.





Recommended ambient and operating temperatures for conventional and synthetic gear lubricants



Note: Ambient temperature is the air temperature measured in the immediate vicinity of the gearbox. A gearbox exposed to the direct rays of the sun or other radiant heat sources will operate at higher temperatures and therefore must be given special consideration. The max operating temp must not be exceeded under any circumstances, regardless of ambient temperature.

If your unit was specified “shaft up” or with a “-Z” option, a grease zerk was provided in the base housing. For shaft-up operation, the output bearing will not run in oil and must be grease lubricated. Use a lithium based or general purpose bearing grease sparingly every 50 operating hours or at regular maintenance intervals. Over-greasing the output bearing should be avoided as it tends to fill the housing with grease and thicken the oil

ESKRIDGE MODEL D440 OIL CAPACITIES

Operating Position	Oil Capacity			Oil Level
	Single stage	Double stage	Triple stage	
 Horizontal Shaft	-	-	-	To horizontal centerline of auger drive 
 Vertical Shaft (Pinion Down)	-	-	4.4 GAL/ 16.8 liters	To midway on upper/primary gear set 



WARNING: While working on this equipment, use safe lifting procedures, wear adequate clothing and wear hearing, eye and respiratory protection.

ESKRIDGE PART NUMBER INTERPRETATION


Note: All non custom Eskridge Geardrives are issued a descriptive part number which includes information regarding the Model, means of shaft retention, base style, shaft style, input mounting, input shaft size, overall ratio and various available options. For a detailed breakdown of this information, please refer to Eskridge product specification sheets found at: <http://www.eskridgeinc.com/diggers/diggerprodspecs.html>

Unit Disassembly Procedure

- 1) Scribe a diagonal line across the outside of the unit from the bail (15B) to the base (1) before disassembly to aid in the proper positioning of pieces during reassembly.
- 2) Remove magnetic drain plugs (14B) and drain oil from unit. The oil will drain out faster and more completely if warm.
- 3) Remove the twenty hex-head capscrews (13A) and lockwashers (13C).
- 4) Separate bail (15B) from ring gear adapter (15A) and remove from digger assembly.
- 5) Install two hex-head capscrews (13A) into ring gear adaptor (15A) to retain gearbox assembly together.
- 6) Remove motor (16) from cover (3).
- 7) Remove the twenty hex-head capscrews (13B) and lockwashers (13C).
- 8) Remove cover (3), thrust bearings (10A, 10B, 10C, 10D & 10E), remove input gear (4). Inspect o-ring (11A); discard if damaged or deformed.
- 9) Remove retaining ring (15F) from stage II sun gear. Lift Stage I planet carrier assembly out of the unit (5). Remove ring gear (8A) and inspect o-ring (11A); discard if damaged or deformed.
- 10) Remove two hex-head capscrews (13A) and ring gear adapter (15A). Inspect o-ring (11B) as before; discard if damaged.
- 11) Remove retaining ring (15G) from stage III sun gear. Lift the Stage II planet carrier assembly out of the unit (7).
- 12) Remove the Stage II ring gear (8B). Inspect o-ring (11B); as before, discard if damaged.
- 13) Using a screwdriver, seal pick or similar tool remove the retaining ring (15H), which retains the Stage III planet carrier to the output shaft. The retaining ring can be left in the carrier but must be removed from the groove.
- 14) With a suitable lifting apparatus and a hoist, lift the Stage III planetary assembly out of the unit (9).
- 15) Remove Stage III ring gear (8C). Inspect o-ring (11B); as before, discard if damaged or deformed.
- 16) The unit is now separated into subassemblies. The area(s) requiring repair should be identified by thorough inspection of the individual components after they have been cleaned and dried.

Stage I Carrier Subassembly

(Items 5A, 5B, 5C, 5D, 5E, 5F & 5G)



Disassembly

- 1) Rotate planet gears (5B) to check for abnormal noise or roughness in bearings (5D) or planet shafts (5C). If further inspection or replacement is required, proceed as follows.

NOTE: Support only the carrier (5A) while pressing out planet shafts.

- 2) Drive roll pins (5G) completely into the planet shafts (5C).
- 3) Press or drive planet shafts (5C) out of carrier (5A).
- 4) Remove planet gears (5B) and thrust washers (5E) from the carrier (5A).
- 5) Inspect the planet gear (5B), bearing bore, planet shaft (5C) and rollers (5D). Check for spalling, bruising or other damage. Replace components as necessary; rollers should be replaced only as a set of 12..
- 6) Check primary planet shafts (5C) for any abnormal wear, especially ones where bearings needed to be replaced. If any abnormal wear is found, replace planet shafts.
- 7) Use 3/16 inch pin punch to remove roll pins (5G) from planet shafts (5C).

NOTE: If either the rollers or the planet shafts (pins) are damaged, both components should be replaced.

Reassembly


- 1) To install rollers in planet gear bore:
 - a) Set planet washer (5E) on work table, insert planet shaft in washer then slide one spacer (5F) over shaft (5C).
 - b) Place planet gear (5B) centered over planet shaft (5C).
 - c) Install twelve rollers into planet gear bore. Slide two spacers (5E) onto planet shaft, slide planet washer (5F) onto planet shaft (5C).
 - d) Carefully remove planet shaft from this assembly and move the gear with bearings and washers to the carrier.
 - e) Slide the gear into place. (Oriented as shown.)
- 2) Planet shafts (5C) should be installed with chamfered end of

3/16 inch hole toward outside diameter of the carrier (**5A**). This will aid in alignment of holes while inserting roll pins (**5G**).

- 3) Drive a roll pin (**5G**) through the carrier hole and into the planet shaft to retain the parts. Repeat for other planet gears.

Stage II Carrier Subassembly

(Items **7A, 7B, 7C, 7D, 7E, 7F, & 7G**)



Disassembly

- 1) Rotate planet gears (**7B**) to check for abnormal noise or roughness in bearings (**7D**). If further inspection or replacement is required, proceed as follows.
- 2) Drive roll pins (**7G**) completely into the planet shafts (**7C**).
- 3) Slide planet shafts (**7C**) out of carrier (**7A**).
- 4) Remove planet gears (**7B**), washers (**7E**) and rollers (**7D**) from carrier (**7A**).
- 5) Inspect the planet gear (**7B**), bearing bore, planet shaft (**7C**) and rollers (**7D**). Check for spalling, bruising or other damage. Replace components as necessary; rollers should be replaced only as a set of 20.
- 6) Remove roll pins (**7G**) from primary planet shafts (**7C**) using a 3/16 inch pin punch.

Reassembly


- 1) Rebuild primary planet carrier assembly in reverse order using any needed new parts.
- 2) Install rollers in gear as follows:
 - a) Set planet washer (**7E**) on work table with planet gear (**7B**) positioned on top of washer. Center the planet washer to the planet gear as closely as possible.
 - b) Center the planet shaft (**7C**) in the planet gear (**7B**) bearing bore. Install roller spacer (**7F**) onto planet shaft.
 - c) Begin placing rollers (**7D**) around the shaft (**7C**). There should be clearance for the last roller to slide in. Be sure to install 20 rollers in each planet gear.
 - d) Place spacer washer (**7F**) onto planet shaft.
 - e) Place a washer over the gear (**7E**) onto the shaft (**7C**).
 - f) Carefully slide the assembly off the table, holding the lower planet washer (**7E**) and planet gear (**7B**).
 - g) Slide the planet shaft (**7C**) out of the assembly and slide the assembly into the carrier.

- h) Align the planet gear/bearing assembly inside the carrier and install the planet shaft through the entire assembly.

- 3) Planet shafts (**7C**) should be installed with the chamfered end of the 3/16 inch hole towards the outside diameter of the carrier (**7A**); this will aid in alignment of holes while inserting roll pins (**7G**).
- 4) Drive roll pin (**7G**) into the carrier hole and into the planet shaft to retain the parts. Repeat for remaining planet gears.

Stage III Carrier Subassembly

(Items **9A, 9B, 9C, 9D, 9E, 9F, 9G & 15H**)



Disassembly


- 1) Rotate planet gears (**9B**) to check for abnormal noise or roughness in bearings (**9D**). If further inspection or replacement is required, proceed as follows.
- 2) Drive roll pins (**9G**) completely into the planet shafts (**9C**).
- 3) Slide planet shafts (**9C**) out of carrier (**9A**).
- 4) Remove planet gears (**9B**), washers (**9E**), spacers (**9F**) and rollers (**9D**) from carrier (**9A**).
- 5) Inspect the planet gear (**9B**), bearing bore and planet shaft (**9C**) and rollers (**9D**). Check for spalling, bruising or other damage. Replace components as necessary; rollers should be replaced only as a set of 40 (2 rows of 20).
- 6) Remove roll pins (**9G**) from secondary planet shafts (**9C**) using a 3/16 inch pin punch.

Reassembly

- 1) Rebuild Stage III planet carrier assembly in reverse order using any needed new parts.

Base Subassembly

(Items 1, 2, 11C, 12A, 12B, 12C, 12D, 14B, 14C, 15C, 15D, & 15E)



Disassembly

- 1) Remove the lock ring (15D) using a heel bar or puller; if using a heel bar, be sure not to pry against the cage of the inner output shaft bearing (12C). Remove the split ring segments (15E) and shims (15C).

Caution: Since the output shaft is no longer retained, care should be taken to avoid personal injury. Care should also be taken not to damage it when it is pressed through base.

- 2) Base (1) should be set pinion side down, as shown, on a plate or table. Press output shaft through the bottom of base by applying a load to top end (internal end) of shaft until it passes through inner shaft bearing cone (12C).

Note: Removing the shaft from the base assembly damages the shaft seal and the seal will need to be replaced.

- 3) A gear puller may be used to remove the outer bearing cone (12A) from the shaft (2). If reusing old bearing cone, do not pull on or damage roller cage. Remove the shaft seal (11C) from the shaft for replacement.
- 4) Inspect inner and outer bearing cups (12B & 12D). If cups are damaged, drive them out using a brass drift and utilizing the bearing knock-out notches in the base (1)

Reassembly

- 1) Clean all foreign material from magnetic oil plug (14C) located on the side of the base (1).
- 2) Place base (1) (output side up, opposite shown) on the table.
- 3) Apply a layer of lithium or general purpose bearing grease to the roller contact surface of outer bearing cup (12A).
- 4) Press outer bearing cone (12B) (large end down as shown) onto the shaft until it seats against the shoulder.

Note: Press bearing cone onto output shaft by pressing on inner race only. DO NOT press on roller cage, as it may damage bearing.

- 2) Place the spiral-wound retaining ring (15H) in the depression at the center of the carrier (9A) in preparation for installation onto the output shaft (2).
- 3) Install rollers in gear as follows:
 - a) Set planet washer (9E) on work table with planet gear (9B) centered on top of washer. Center the planet washer and the planet gear as closely as possible.
 - b) Slide a spacer (9F) over the planet shaft.
 - c) Center the planet shaft (9C) in the planet gear (9B) bearing bore.
 - d) Begin placing rollers (9D) around the shaft (9C). There should be clearance for the last roller to slide in. Be sure to install 20 rollers per row in the planet gear (9D).
 - e) Slide a spacer (9F) over the first row of rollers (9D).
 - f) Place a second row of rollers (9D) around the planet shaft (9C) as before.
 - g) Slide a spacer (9F) over the second row of rollers (9D).
 - h) Place a washer (9E) over the gear (9B) onto the shaft (9C).
 - i) Carefully slide the assembly off the table, holding the lower planet washer (9E) and planet gear (9B).
 - j) Slide the planet shaft (9C) out of the assembly and slide the assembly into the carrier (9A).
 - k) Align the planet gear/bearing assembly inside the carrier and install the planet shaft through the entire assembly.
- 4) Planet shafts (9C) should be installed with the chamfered end of the 3/16 inch hole towards the outside diameter of the carrier (9C). This will aid in alignment of holes while inserting roll pins (9G).
- 5) Drive roll pin (9G) through the carrier hole and into the planet shaft to retain the parts. Repeat for the other planet gears.

- 5) Place the shaft (2) with the bearing (12A) into the base (1).
- 6) Flip this assembly, resting the base (1) on the end of the output shaft (2).
- 7) Apply a layer of lithium or general purpose bearing grease to the roller contact surface of the inner cup (12D). Press the inner bearing cone (12C) (large end up as shown) onto the shaft (2) until it is seated against inner bearing cup (12D).
- 8) Without the shaft seal (11C) installed, the preload may result in a rolling torque that varies between 50 to 300 in-lb. The bearing preload should be tailored to your application; a low-speed application may require a high pre-load, high-speed applications usually benefit from low pre-load. Adding shims (15C) will increase the pre-load on the bearing set. Determine your pre-load requirement and install shims to obtain this pre-load. Install the Load-N-Lock™ segments (15E) over the shims (15C) and into the groove in the shaft (2). Finally, install the lock ring (15D) over the segments (15E).
- 9) Lubricate inner lip of new shaft seal (11C) and slide it onto the shaft (2) and over the shaft seal diameter then press the seal into the base bore (1).

All subassembly service or repairs should be complete at this time. Continue to Unit Assembly to complete unit buildup.

Unit Assembly

- 1) When all subassemblies are complete, the unit is ready to be assembled.
- 2) Install the Stage III carrier assembly onto the output shaft; align the splines of the carrier (9A) with the splines of the shaft (2) and slide the carrier onto the shaft.
- 3) Install the retaining ring (15H) onto the groove of the shaft (2), using a spiraling motion.
- 4) Lubricate o-ring (11B) and install on the pilot of the Stage III ring gear (8C).

Caution: Hold ring gear by outside or use lifting device to prevent injury.

- 5) Install Stage III sun gear (6B) into Stage III carrier assembly.
- 6) Align gear teeth of ring gear (8C) with the gear teeth of the planet gears (9B) and place on base. Align mounting holes of ring gear with holes in base. Using the scribed line made during disassembly for reference.
- 7) Slide Stage II carrier (7A) onto Stage III sun gear (6B) then install retaining ring (15G) onto sun gear groove using a spiraling motion.
- 8) Lubricate o-ring (11B) and install on the pilot of the Stage II ring gear (8B).
- 9) Align gear teeth of ring gear (8B) with those of the planet gears and place on Stage III ring gear. Align mounting holes of ring gear with holes in base. Use the scribed line made during disassembly for reference.
- 9) Lubricate o-ring (11B) and install on the pilot of the Stage I ring gear adaptor (15A).
- 10) Noting the scribed line made during disassembly, install the

Stage I gear adapter (15A) and temporarily install two fasteners (13A) to hold assembly together.

- 11) Install the Stage II input gear (6A) and Stage I carrier assembly (5) onto the Stage II input gear. Place retaining ring (15F) onto sun gear groove using a spiraling motion.
- 12) Align gear teeth of ring gear (8A) with the gear teeth of the planet gears (5B) and place on ring adaptor. Align mounting holes of ring gear with holes in base. Using the scribed line made during disassembly for reference.
- 13) Install the input gear (4) then thrust bearings in the following order onto the input gear: carrier thrust washer (10D), case thrust washer (10E), one thrust washer (10B), thrust bearing (10C), one thrust washer (10B), and thrust spacer (10A).
- 15) Lubricate o-ring (11A) and install on the pilot of the cover (3).
- 16) Noting the scribed line made during disassembly, install the cover (3).
- 17) Install and torque the 20 5/8-11 hex-head cap-screws (13B) with lockwashers (13C). The torque for the cap-screws: **220 ft-lb dry, 170 ft-lb if the fasteners are lubricated.**
- 18) Ensure the unit spins freely by using a splined shaft to drive the input gear (4).
- 19) Install motor (16) onto cover (3B) and align motor shifting mechanism with bail relief hole. Install motor fasteners.
- 20) Remove two temporarily fasteners installed in step 10. Place bail (15B) onto assembly and aligning holes in bail and cover using scribed line made during disassembly as a reference. Install and torque the 20 5/8-11 hex head capscrews (13A) with lockwashers (13C). **The torque for the capscrews is 220 ft-lbs dry, 170 ft-lbs if fasteners are lubricated.**
- 21) Fill the unit to the proper level, as specified, with GL5 EP 80/90 gear oil after it is sealed with a brake and/or motor.

The digger is now ready to use.